

SHOWER and CUBICLE CURTAINS

Recommended Care

Sure-Chek healthcare fabrics offer "clean-in-place" convenience. Any soils or stains that may accumulate on the fabrics' surfaces should be removed periodically for a fresh new appearance. Use neutral soap suds and lukewarm water. Then rinse with water and allow fabric to dry.

Hard to Clean Spots: Standard household/vinyl cleansers and/or a soft bristle brush can be used for removing troublesome spots or stains. Heavy "dried on" soil may first require soaking to loosen. **DO NOT USE HARSH CLEANSERS OR SOLVENTS.**

Herculite Products, does not recommend the laundering of Sure-Chek healthcare fabrics since laundering may substantially decrease the useful life of these fabrics. However, if laundering is required, follow the procedures of the International Fabricare Institute:

1. Wash and rinse according to the "Synthetic Washing Procedure for Coated Fabrics" with temperatures not exceeding 100° F. (see below).
2. Extract water with centrifugal extractor.
3. Tumble dry in a steam dryer (not gas) at 120° F. maximum. For tailored, precise fitted items, tumble dry without heat or air dry. **DO NOT IRON.**

Synthetic Washing Procedure for Coated Fabrics

(International Fabricare Institute Commercial Washroom Procedures)

Operation	Water	Time Level	Maximum Temperature	Supplies
1st Suds	High	5 Min.	100° F	Neutral Soap & Alkali
2nd Suds	High	10 Min.	100° F	Neutral Soap & Alkali
1st Rinse	High	3 Min.	100° F	Water
2nd Rinse	Low	3 Min.	90° F	Sour to pH 5.0

Use a slow speed machine. Stop the wash wheel for draining and refilling between each cycle.